Traffic Engineering within MPLS Information Distribution

Sources:

MPLS Forum

E. Osborne and A. Simha, Traffic Engineering with MPLS, Cisco Press

MPLS Traffic Engineering – Information Distribution

- Value added services enabled by MPLS Traffic Engineering
 - Constraint-based routing
 - ✓ QoS
 - ✓ Fast reroute
 - ✓ VPNs
 - \checkmark
- What's involved in information distribution to support TE

Review Terminology...


Network Engineering

- ✓ "Put the <u>bandwidth</u> where the <u>traffic</u> is"
 - Physical cable deployment
 - Virtual connection provisioning

Traffic Engineering

- ✓ "Put the <u>traffic</u> where the <u>bandwidth</u> is"
 - Local or global control
 - On-line or off-line optimization of routes
 - Implies the ability to "explicitly" route traffic


Traditional Traffic Engineering



Move traffic from IGP path to less congested path

Traditional Traffic Engineering


Limitations



- TE Mechanisms
 - Over-provisioning
 - Metric manipulation

- Limitations
 - Some links become underutilized or overutilized
 - ✓ Trial-and-error approach


Traffic Engineering with ATM Core



- Infrastructure
 - Routed edge over ATM switched core
 - ✓ Introduced full Traffic Engineering (TE) ability

Traffic Engineering with ATM Core

Logical Topology




- TE Mechanisms
 - ✓ VC routing
 - Overlay network
- Benefits
 - ✓ Full traffic control
 - Per-circuit statistics

- Limitations
 - Overlay of IP and ATM
 - ✓ "N-squared" VCs
 - ✓ IGP Stress
 - ✓ Cell tax

MPLS Traffic Engineering


- Traditional TE controls traffic flows in a network
 - "The ability to move traffic away from the shortest path calculated by the IGP to a less congested path"
- MPLS Traffic Engineering
 - ✓ Allows Explicit Routing and set-up of LSP's
 - Provides control over how LSP's are recovered in the event of a failure
 - Enables Value Added Services
 - Virtual Private Networks VPNs
 - Service Level Agreements SLAs
 - Multi-media over IP solutions MMoIP, VoIP
 - > ATM over IP easy and cheap for existing legacy networks

Review Topology and LSP set-up



But, this is a simple example . . .

- Routing Protocols Create a "Shortest Path" Route
- LSPs follow the "shortest path"



This mechanism does NOT give us Traffic Engineering

MPLS Traffic Engineering

Requires 3 main areas of extensions

- Enhancements to the <u>Routing Protocols</u>: <u>Information</u>
 <u>Distribution</u>
 - ✓ OSPF → OSPF-TE
 - ✓ ISIS → ISIS-TE
- Enhancements to SPF to consider constraints: Constraint-Based Routing (CSPF): Path Calculation
 - Explicit route selection
 - Bandwidth parameters and recovery mechanisms defined
 - Connection Admission Controls (CAC) enforced
 - (policing, marking, metering, scheduling, etc)
- Enhancements to the <u>Signalling Protocols</u> to support explicit constraint-based routing: <u>Path Creation</u>
 - ✓ LDP → CR-LDP
 - ✓ RSVP → RSVP-TE

What's involved in information distribution to support TE?

- Information distribution is broken down into three pieces:
 - ✓ What information is distributed and how to configure it
 - When information is distributed and how to control when flooding takes place
 - How information is distributed (protocol-specific details)

What information Is Distributed?

- The idea behind MPLS TE is to allow routers to build paths using information rather than the shortest IP path. But what information is distributed to allow the routers to make more intelligent path calculations?
 - Examples:
 - > Path that has enough bandwidth, special attributes, low delay, ...
 - Generally, information that has to do with TE objectives/requirements
- MPLS TE works by using OSPF or IS-IS to distribute information about available resources. Three main pieces of information are distributed for each link/interface:
 - Available bandwidth information, broken down by priority to allow tunnels to preempt others
 - Attribute flags
 - Administrative weight

Available Bandwidth Information

- A key feature of MPLS TE is the capability to reserve bandwidth across the network
- How much bandwidth to allocate to the interface?
 - Also depends on oversubscription policies and the policy to enforce them
 - ✓ Cisco default is 75% of the link bandwidth
- Main elements: interface, allocated, max, percentage. Example:
 - P04/2 233250K 466500K 50
- Need to keep track of currently allocated bandwidth to obtain currently available or reservable bandwidth
- Need both the per-interface and the per-tunnel (TE LSP) bandwidth
 - ✓ Why both?

Tunnel Priority

- Some LSPs or tunnels are more important than others.
 For example, tunnels for voice traffic.
- Need capability to allow tunnels to preempt others.
 - Each tunnels has a priority
 - ✓ Lower-priority tunnels are pushed out and are made to recalculate a path, and the resources are given to the higher-priority tunnel
 - ✓ 8 priority levels (0-7)
 - Destructive to other tunnels, use only necessary
 - In a real network, the preempted tunnel can have an alternative path for backup and the tunnel will come up
 - Example

Setup and Holding Priority

- Each tunnel actually has two priorities a Setup priority and a Hold priority (RFC 3209)
- Idea is to use Setup priority to decide whether to admit the tunnel, Hold priority is used to compare priority if competition comes along for a new tunnel
 - Usually treated the same, but can be different
 - ✓ Application: once the tunnel is setup, the Hold priority could be set to the highest, which means that it cannot be preempted by any other tunnels.
 - ✓ But Hold priority must be >= Setup priority, why?

Attribute Flags

- MPLS TE allows you to enable attribute flags.
- An attribute flag is a 32-bit bitmap on a link that can indicate the existence of up to 32 separate properties of that link.
 - ✓ ISPs have the freedom to manage these bits
 - Example:
 - Assuming 8-bit and a link that has attribute flags of 0x1 (0000 0001) means that the link is a satellite link.
 - If you want to build a tunnel that does not cross a satellite link, you need to make sure that any link the tunnel crosses has the satellite link bit set to 0
 - Need a mask

Administrative Weight or Metric

- For MPLS TE, two costs are associated with a link – the TE cost and the IGP cost.
 - ✓ Allow to present the TE path calculation with a different set of link costs than the regular IGP SPF sees.
 - ✓ In other words, you can change the cost advertised for the link, but only for traffic engineering. Why?
 - Useful in path calculation. Examples:
 - Networks that have both IP and MPLS TE traffic
 - Delay-sensitive link. Example: OC-3 land line and OC-3 satellite link have different delays, but with the same bandwidth.

When Information Is Distributed?

- IGP floods information about a link in three cases:
 - When a link goes up or down
 - ✓ When a link's configuration is changed (e.g., link cost)
 - ✓ When it's time to periodically flood the IGP information
- For MPLS TE, there is more to consider:
 - When link bandwidth changes significantly
 - Link attribute(s) changed
- What is "significant"?

What is Significant?

- How to define significant?
 - Percentage of link bandwidth
 - ✓ Is it enough?
 - ✓ Rules are different for every network, situation, and link
 - Cisco uses default flooding thresholds (15, 30, 45, 60, 75, 80, 85, 90, 95, 96, 97, 98, 99, 100) on links. If the thresholds are crossed, link bandwidth is flooded.
- Flood insignificant changes periodically
 - ✓ If available bandwidth has changed and it hasn't been flooded, the changes will be flooded every 3 minutes (default value, but configurable), more frequently than IGP refresh interval
- If error, flood immediately
 - A path setup fails due to lack of bandwidth. Available bandwidth has been changed since the last time flooding occurred.
- Should be considered in TE methods.

How Information Is Distributed?


- MPLS TE in OSPF, hence OSPF-TE
- MPLS TE in IS-IS, hence ISIS- TE
- MPLS TE enhancements and IP-Extended TLVs are closely related.
 - ✓ Type 1: router address TLV: MPLS TE router ID
 - ✓ Type 2: link TLV: 9 sub-TLVs
 - Link type, link ID, local I/F IP addr, remote I/F IP addr, *TE metric* (cost, admin-weight), max link bw, max reservable bw, unreserved bw (per priority), attribute flags.
- Before you can do MPLS TE, support for wide metrics must be enabled.

Constraint-Based Routing

Constraint-Based Routing

- Parameters over and above "best effort" are constraints
 - Constraint = order in which LSRs are reached
 - Constraint = description of traffic flow, bandwidth, delay, class, priority
 - Constraint = edge traffic conditioning functions such as marking, metering, policing, and shaping
 - ✓ <u>Constraint</u> = Recovery mechanism for "protection" of a working LSP
- Supports and enables QoS/CoS functions for;
 - IP DiffServ and IntServ

Constraint Route Signaling Operational Model



- 1) Store information from IGP flooding
- 2) Store traffic engineering information

OSPF and IS-IS - TE Extensions


Distributed (piggybacked) on Opaque Link State Advertisements

Encoded as new Type Length Values (TLVs)


Metrics: Bandwidth, Unreserved Bandwidth, Available Bandwidth, Delay,

Delay-Jitter, Loss Probability, Administrative Weight, Economic Cost

Constraint Route Signaling Operational Model




Constraint Route Signaling




- Operator configures LSP constraints at ingress LSR
 - Bandwidth reservation
 - ✓ Include or exclude a specific link(s)
 - ✓ Include specific node traversal(s)
- Network actively participates in selecting an LSP path that meets the constraints

Constraint Route Signaling Example



Constraint Route Signaling Example



Signaling Mechanisms

LDP Label Distribution Protocol

CR-LDP Constraint-Based Routing - Label

Distribution Protocol

RSVP-TE Extensions to RSVP for Traffic

Engineering

BGP-4 Carrying Label Information in

BGP-4

Constraint-Based Routing

- CBR could be very challenging and complicated.
 - Example: need to deliver 60 bricks with only one bike.
 - ✓ Solution?

✓ If > 1 constraint:
NP-complete

